Fuel Poverty

Fuel poverty refers to a condition where a household is unable to afford sufficient energy to maintain a healthy and comfortable living environment. In the UK, a household is officially considered to be in fuel poverty if it meets the following criteria:

- **Required Fuel Costs Above Average**: The household needs to spend more than the national average on energy to maintain adequate heating, lighting, and other essential energy services.
- Below Poverty Line After Energy Costs: If the household were to spend the required amount on fuel, their remaining income would fall below the official poverty line, leaving insufficient funds for other basic needs such as food, clothing, and healthcare.

Fuel poverty is a significant issue in the UK, exacerbated by rising energy costs, inefficient housing stock, and low household incomes. It is closely linked to housing quality, as poorly insulated homes with outdated heating systems require more energy to achieve comfortable temperatures. This makes addressing fuel poverty a priority in both new builds and retrofit projects.

The UK government measures fuel poverty using the **Low Income Low Energy Efficiency (LILEE)** framework, which considers both income levels and the energy efficiency of a home. Improving a home's energy efficiency (e.g., through insulation, double glazing, or efficient heating systems) is seen as a key strategy for alleviating fuel poverty.

Real-World Applications and Examples:

1. Energy Efficiency Retrofits:

Programmes such as the **ECO** (Energy Company Obligation) scheme and PAS 2035 retrofits focus on upgrading the energy efficiency of homes occupied by low-income households. Measures like loft insulation, cavity wall insulation, and replacing inefficient boilers directly reduce required fuel costs, lifting households out of fuel poverty.

2. Social Housing Projects:

Local authorities and housing associations often implement energy-saving measures in social housing to combat fuel poverty. For example, retrofitting older council homes with **mechanical ventilation with heat recovery (MVHR)** systems ensures adequate ventilation while minimising heat loss, reducing heating costs.

3. Impact of Rising Energy Prices:

During the 2021–2022 energy crisis, many households that were previously managing their energy costs found themselves in fuel poverty due to sharp increases in energy tariffs. This highlighted the importance of resilient design in housing and the need for government support schemes like the **Warm Home Discount**.

Practical Implications:

- **Building Regulations**: Approved Document L (Conservation of Fuel and Power) sets energy efficiency standards for new builds and retrofits, directly addressing the root causes of fuel poverty.
- Retrofit Standards: PAS 2035 mandates a whole-house approach to retrofitting, ensuring
 that energy efficiency measures are implemented holistically to maximise benefits for fuel-poor
 households.
- **Policy Interventions**: Government schemes, such as the **Boiler Upgrade Scheme** or **Home Upgrade Grant**, aim to reduce fuel poverty by subsidising energy efficiency improvements in

low-income homes.

Fuel poverty is not just a financial issue but a public health and housing quality challenge. Addressing it requires a combination of energy efficiency improvements, targeted government support, and adherence to building standards that prioritise sustainable and affordable energy use.